


For Recall-It to work, you need 2 things on your console: the multiplexers found on the channels and the bus driver. The multiplexers are the same for all console channels. The Bus Driver looks different on E-type and G-type consoles, though its function is the same.


Recall Multiplexers

Every recallable channel needs to have the multiplexer card installed and functional. You'll need to remove a channel to see if you have the board installed. See image below for where to find it.




E-type console Bus Driver

To find the bus driver on E-type consoles, look under the keyboard section for the Total Recall bus driver mezzanine card. Not all consoles have this installed and it's necessary for Recall-It to work.



G-type console Bus Driver

On G-type consoles, the bus driver is integrated with the keyboard interface and needs all chips on the board for Recall-It to work.



That's all there is to it! If the required chips are present and functional, your console will work with Recall-It.